

DALDORADO

WARNING /DANGER/ ATTENTION

CUSTOM GRATE INSTALLATION INSTRUCTIONS

These grates are for Non-Submerged GRAVITY Outlets ONLY

Product Reference: DMD-FGO-NS-CU

- When installing and using this equipment, basic precautions shall always be followed, INCLUDING THE INSTALLATION INSTRUCTIONS.
- READ, FOLLOW, AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS and then keep them for future reference. If there are any questions or further information needed call 1-888-509-8128 for assistance.
- Install frame and grate and/or grate only on existing concrete ledge. The ledge must be a minimum of 1-inch wide. Drill 5/16" holes with a concrete bit to the depth of 1" for the 316 SS drop-in anchors. The anchors should be set 2" from the corner, approximately every 20" across the length of the grate. There must be a minimum of four (4) anchors per grate.
- Hand start the supplied stainless-steel screws through fastening clips to ensure they do not strip out the 3/16 SS drop-in anchor. Tighten down tamper proof screw until fastener is snug, do not over tighten. DO NOT USE POWER TOOLS.
- The spray/splash pad shall not be operated if the cover is missing, broken or has become unsecured in such a way that it can be removed without the use of tools.
- Grates and fasteners should be inspected during regular maintenance periods (at least once per year).
- The use of adhesives or other attachment methods that prevent access to drain piping is prohibited.
- When winterizing, grate must be reinstalled per original installation instructions.
- All Grates shall be installed in accordance with the manufacturer's installation instructions.
- No modifications shall be made to either the frame or grate.
- Any modification of any kind to any Daldorado product will void all warranties.

DALDORADO, LLC., 4327 ARNOLD AVENUE, NAPLES, FL. 34104

For Inquiries or Assistance please call: (888)-509-8128